



# LINK 340

## Monitor your assets and vehicles on one interface

The LINK 340 asset tracking device, combined with Webfleet, gives you visibility over your assets' positions and usage. You can monitor all the powered assets and vehicles in your fleet from one interface, supporting you to manage your assets better. Meanwhile, automated processes and notifications help you reduce workload.

## BENEFITS



### STAY IN CONTROL AT ALL TIMES

- Notifies you when your asset is moved, deterring unauthorized usage and allowing you to react quickly to theft.
- Minimizes risk from theft, loss or misplacement with clear visibility of your assets.



### REDUCE WORKLOAD WITH AUTOMATED ASSET MANAGEMENT

- Provides positions and automated reporting on the way your assets are used.
- Tracks your assets alongside your fleet on one interface.
- Improves accuracy and efficiency of rental billing or asset bookkeeping.



### SAVE COSTS AND MAINTAIN THE VALUE OF YOUR ASSETS

- Supports scheduled maintenance tasks to help avoid costly downtime.



## FEATURES



### TRACK AND MONITOR

View current positions plus mileage and movement statuses to get a fuller understanding of how your assets are being used.



### INSTANT ALERTS

Get notified whenever an asset's status is changed, e.g. it enters or leaves a defined area, or a movement is detected.



### TRACE VIEW

Gain visibility into where your assets have been with position updates every five minutes on the map.<sup>1</sup>



### MAINTENANCE NOTIFICATION

Schedule and manage your asset's maintenance tasks easily based on the odometer, engine hours or time since the last maintenance.



### ASSET UTILIZATION REPORT

Get 24/7 access to reports regarding your assets, including current position, trip, maintenance, address/location and input reports (e.g. trailer door status).



### DAILY ASSET HEARTBEAT CHECK

The internal battery in the LINK 340 gives a daily update of your asset's location when it is not in use.<sup>2</sup>



### ENGINE HOURS

Get a better understanding of how your machinery is being used by monitoring the engine running time of your assets.



### COUPLING

If your vehicle is also equipped with a LINK tracking device, the coupled asset information is displayed automatically on the map for both vehicles and assets. You can easily identify which asset is connected to which vehicle.



18 PIN interface



Power LED / GPS LED / CEL LED

## SPECIFICATIONS

### Dimensions:

5.31 (L) x 2.44 (W) x 1.50 inch (H)

Weight: 6.67 oz

Supply voltage: 12 V / 24 V  
(min 8 V to max 32 V) DC

### Temperature operation:

Operation: -4 °F to +140 °F

Storage: -40 °F to +140 °F

Protection class: IP67

Mobile networks: Integrated mobile network antenna and module.

• LTE-M B1/B2/B3/B4/B5/B8/B12/B13/B18/B19/B20/B25/B28

• EGPRS 900/1800MHz

GPS: Integrated GPS antenna and GPS receiver

Rechargeable battery: Li-Ion battery, 3.7 V, 5800mAh

Digital input: 4 negative trigger input

<sup>1</sup> Trace view does not provide the exact routes the assets have traveled.

<sup>2</sup> Available over a maximum period of 90 days when the LINK 340 battery is fully charged. When the asset is in use, the tracking rate is 1 position every 5 minutes.